


SWITCHES

ITEM#	ITEM DESCRIPTION
-------	------------------

58.2	AbleNet Switch 100 (loan unit 2)
42	Adaptive Fixtures Kit-Zygo
169	AirLink Cordless Switch
31	Bass Switch
76	Chin Switch & Bracket
745	Cordless Switch
892	Finger Isolation Switch (Bitty Bubble)
852	Glitter Roll Music Box/Switch
238	Jelly Bean Switch (Yellow)
558.1	Large Battery Wafer
851	Medium Oval Texture Music Box/Switch
62	Piezoelectric switch (P-Switch)
66	Pig Switch
137	Pneumatic Switch (PS-2)
401	Sip or Puff Switch
347	Sip & Puff Switch
557.1	Small Battery Wafer
850	Small Oval Texture Switch
52	Sound Activated Switch
245	Spec Switch Red
512	String Switch
513	The Ultimate Switch
69.1	Zygo Red Tread Switch
41	Zygo Switch Kit
65	Zygo Tread Switch, Loan Unit 1



SWITCHES

ITEM DESCRIPTION (New designates a new item)	TYPE	ITEM#
AbleNet Switch 100 (loan unit 2) Big red switch - emits click when activated.	SW	58.2
Adaptive Fixtures Kit-Zygo Component pieces which can be assembled to make a switch mounting. Zygo. www.zygo-usa.com	SW	42
AirLink Cordless Switch Activates appliances connected to PowerLink 2 without cords. Cordless flexibility activates the PowerLink 3 Control Unit from up to 20 ft away. Add the 5' cord for use with devices other than the PowerLink. Ablenet. www.ablenetinc.com	SW	169
Bass Switch 6"x 3.75" x 1" flat large surface with auditory click feed back. 5 overlay colors to choose from. Don Johnston Inc. www.donjohnston.com	SW	31
Chin Switch & Bracket Switch operated by pressure from the chin; used w/ chest-mounted bracket.	SW	76
Cordless Switch AbleNet Cordless switch control of communication aids, computers, large and small electrical appliances, battery operated toys and more. Ablenet. www.ablenetinc.com	SW	745
Finger Isolation Switch (Bitty Bubble) Recessed button for one finger. Works as a switch or a multi-sensory activity center that activates lights, music and vibration. Enabling Devices. www.enablingdevices.com	SW/T	892
Glitter Roll Music Box/Switch Multi-sensory stimulation with roller action and built in music box. Can also work as a switch when hooked to a toy and activated. Enabling Devices. www.enablingdevices.com	SW	852
Jelly Bean Switch (Yellow) A light pressure activation switch designed to provide audible feedback to the user. Ablenet. www.ablenetinc.com	SW	238
Large Battery Wafer A large copper disc that goes between the battery and the contact of the toy or appliance.	SW	558.1
Medium Oval Texture Music Box/Switch Designed to provide auditory, tactile and visual stimulation. Acts as a music box or a switch. Enabling Devices. www.enablingdevices.com	SW	851
Piezoelectric switch (P-Switch) Very sensitive switch reacts to muscle electricity. Includes cables, sensor kit, switches.	SW	62

SWITCHES

ITEM DESCRIPTION (New designates a new item)	TYPE	ITEM#
Pig Switch Bright colored switch in the shape of a pig. Light touch is all that is needed to activate. Enabling Devices. www.enablingdevices.com	SW	66
Pneumatic Switch (PS-2) Permits control by blowing and sucking on tube. Push button also included for manual use.	SW	137
Sip or Puff Switch A sip and puff switch. To activate one switch, you "sip" and to activate the other, you "puff". Internal saliva trap allows for easy cleaning. ZYGO Inc. www.zygo-usa.com	SW	401
Sip & Puff Switch Two switches in one with gooseneck mount. Enabling Devices. www.enablingdevices.com	SW	347
Small Battery Wafer A small copper disc between the battery and the contact of the toy or appliance.	SW	557.1
Small Oval Texture Switch Brightly colored with bumpy texture for tactile stimulation. Enabling Devices. www.enablingdevices.com	SW	850
Sound Activated Switch This ultra-sensitive switch responds to a whisper or a loud clap. Easily set the sound threshold level to which the switch responds. Adjust the length of time the switch will stay on after initial activation. Enabling Devices. www.enablingdevices.com	SW	52
Spec Switch Red A light pressure activation switch designed to provide audible feedback to the user. 1/4 inch in diameter. Ablenet. www.ablenetinc.com	SW	245
String Switch A switch that is easily activated by anyone with limited movement. It has suction cups for attachment to most surfaces. Enabling Devices. www.enablingdevices.com	SW	512
The Ultimate Switch This switch has a small ball protruding from a 2.5" inch stick mounted on a gooseneck and a clamp for easy attachment. Enabling Devices. www.enablingdevices.com	SW	513
Zygo Red Tread Switch Light touch switch with red touch panel. Includes switch and cable. Zygo. www.zygo-usa.com	SW	69.1
Zygo Switch Kit Several switches in a kit form for assessment. Includes tread switch; touch switches; pneumatic switch with squeeze ball; long leaf switch, short leaf switch and thumb switch. Zygo. www.zygo-usa.com	SW	41

SWITCHES

ITEM DESCRIPTION (New designates a new item)	TYPE	ITEM#
Zygo Tread Switch, Loan Unit 1	SW	65
CM-1 medium pressure switch with audible click, includes switch and cable.Zygo. www.zygo-usa.com		

